


Nirvana Ultrasonic Aroma Diffuser




IMPORTANT INSTRUCTIONS — RETAIN FOR FUTURE USE

Congratulations on your purchase of the **Pure Essential Oil Works Nirvana Ultrasonic Aroma Diffuser**. Please read the instructions and safety tips before use. Your diffuser comes with a one-year limited warranty. If for any reason you need service, please call 800-520-6000.


This aroma diffuser uses ultrasonic technology to mist the water without heat for the most beneficial results





How to Operate

- 1. Put the unit in stable position. Remove the cover vertically. See *FIG1*.
- Attach the AC plug to the DC-IN jack on the bottom of the unit. See FIG2.
- Add clean water to the water tank without exceeding the maximum waterline of 300 ml. DO NOT refill while the unit is in operation. DO NOT use hot water or mineral water.
- Add essential oil into the water (Advise one drop oil per 100 ml water). Use more or less oil depending on the level of intensity you prefer. See FIG2.
- Put the cover back on the unit, rotate the cover to adjust the mist outlet to the right position. DO NOT switch on the unit without the cover shielding the water tank.
- 6. Attach the AC adapter plug to power outlet.
- Press the "Light" button to select the LED light to change gradually or to a fixed color by pressing button again during auto changing mode. Press and hold button for 3 seconds to turn light off. See FIG3.
- 8. Press the "MIST" button to switch on and start in continuous mode. To switch to intermittent mode, press and hold "MIST" button for 2 seconds. The indicator light will flash and the diffuser will make two "beeps". To return to continuous mode, hold button for 2 seconds again and the diffuser will make one "beep." Press the "MIST" button to set the desired duration, choose from 2H, 4H, Co (continuous) or OFF. The unit will power off automatically when it reaches the end of operating time. See FIG3.





When not in use for an extended period, pour any remaining water from the reservoir before storing it in a cool and dry place.

10. If the water level inside the unit runs too low, the unit will automatically stop operating.


Maintenance


For best operation and safety, please follow these steps if diffuser has been used for 5-6 times or 2-3 days:











6. If it is dirty inside the mist outlet, please remove the inner cover to clean it.





Note:

- Do not use the medical dilution benzene ethanol on unit. This can cause damage to the product or smear the markings on the product.
- Be sure to use a neutral detergent.

Precautions

In order to avoid damage to the diffuser:

- Do not modify, disassemble or repair this product. If for any reason you need service, please call 800-520-6000.
- Do not stab, twist or stretch the power cord. Do not place near heat. If the power cord is damaged or the socket is loose, please do not operate unit.
- Place unit on a flat, stable surface.
- Drain water after each use from the drain outlet side of unit.
- Only use neutral detergent to clean the unit.
- Do not allow mist to spray directly at person.
- Disconnect adapter from power outlet when performing maintenance.
- Do not put nails, needles or other objects at air outlet or the gap of the main body.
- Use only tap water in unit.

Specifications

Power

Size 5.2" Round X 4.3"H

Weight About .56 lbs. (adapter not included)

Supply power: input AC100-240V 50/60Hz

DC 24V 650mA 10W

Ultrasonic frequency 2.4MHZ

Timer 2H/4H/Co (continuously working until waterless)

Mist 35 ml/H

Water capacity 10 oz./300ml

Main material

Accessories Adapter, user manual



Item #308185

pureessentialoilworks.com • 800.520.6000 tng worldwide • New Hudson, MI 48165 ©2017 TNG • Made in China