



Fleece Massage Table Warmer User Manual

CLEANING & MAINTENANCE

- When not in use and before cleaning the blanket, disconnect it from electricity.
- Disconnect the controller from the blanket.
- Do NOT immerse the controller in water or get them wet.
- Clean the surface of the cord with neutral detergent if the cord is dirty and wipe it dry with soft cloth.
- Do not dry clean this blanket as it could damage the heating elements.
- Do not use industrial solvents such as benzene, kerosene or similar solvents to clean it.
- Machine washing of the blanket is possible. However, hand wiping it down will prolong the life of the blanket. To machine wash, remove the controller and place the blanket in a net bag and seal it. Use a small amount of detergent and set the washing machine to "Delicate Wash" with a maximum temperature of 104° F. When washed, remove the blanket from the net bag and drape it over a clothes line to dry.
- Do NOT wring out the blanket.
- Do NOT dry using a tumble dryer.
- Do NOT iron the blanket.
- Do NOT dry the blanket in the sun.
- Do NOT connect it to the power supply to dry it.
- Do NOT use an appliance such as a hair dryer to dry it.
- Allow the blanket to dry naturally.
- Do NOT use the blanket if it is damp or wet.
- Do NOT try to repair the blanket if faulty – have it looked at by a qualified repair person.
- Examine the blanket frequently to check that there are no signs of wear or damage. If any damage/wear is spotted, do not use the blanket.

STORAGE

- When not in use, allow blanket to cool down before folding, then gently fold and place back into the packing bag it arrived in.
- Make sure the blanket is dry before folding and packing away.
- Do not use mothproofing agents on the blanket.
- Insulation of the blanket will be damaged if the blanket is ironed. Damage to the insulation material will cause safety problems.
- Do not crease the blanket by placing items on top of it during storage.
- Store in a cool, dry place.



Item #490240

tng worldwide • New Hudson, MI 48165

tngworldwide.com • 800.520.6000

©2017 TNG • Made in China

Item #490240

IMPORTANT INSTRUCTIONS — RETAIN FOR FUTURE USE

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of personal injury or damage to property, basic important safety instructions must be observed including the following:

- Read the instruction manual thoroughly and retain for future reference. Ensure you know how the electric blanket works and how to operate it before use.
- Always turn the power off at the power outlet before you insert or remove a plug. Remove by grasping the plug. Do not pull on the cord.
- Turn the power off and remove the plug when the electric blanket is not in use or before cleaning.
- Always use the electric blanket from a power outlet of the voltage (A.C. only) marked on the rating label.
- Use only the type of controller marked on the rating label.
- Do not use if blanket is damp or wet.
- This blanket is not intended for medical use in hospitals.
- Do not use together with another heating appliance.
- The blanket is not intended for use by persons (including children) with reduced physical, sensory or mental capacities or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the blanket by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the blanket.
- If the supply cord of this blanket is damaged, it must only be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- This blanket must not be used by persons insensitive to heat and other very vulnerable persons who are unable to react to overheating.
- Children under the age of three are not to use this appliance due to their inability to react to overheating.

Fitted Electric Blankets

- The appliance should not be used on an adjustable bed.
- Place blanket on bed with the mains lead at the pillow end. Ensure the controller emerges from the top side of the blanket and that heating elements do not emerge under the pillow area.
- The four clasps on the corners should be fixed tightly to the bed to prevent the blanket from moving or creasing. (The creased part tends to cause high temperature which is very dangerous.)

USING THE BLANKET

- Connect the controller to the blanket (The blanket has a socket attached that the controller slots into) and ensure it is fully connected.
- Ensure there is a mains supply nearby and that, when in use, the mains lead will not be in a position that could create a trip hazard. When plugged into the mains supply, the controller must be within easy reach of the user.

Remote operating functions:

Please set preheating at the highest tap position 30-60 minutes before using. When using, select the appropriate tap position according to feeling. If the user will go to sleep or use for a long time, please set at "1" tap position (which is the lowest position) to avoid overheating.

• Application method

The starting up state is the standby state. The yellow indicator light is on.

- Press TEMP and display the temperature at one tap position and the timing state at eight hours.
- Continuously press TEMP. The displayed temperature will circulate from one to five tap positions. The corresponding red indicator light will display from one light to five lights. When setting at high temperature (tap position with five red indicator lights on), it will automatically change to low temperature tap position with one red indicator light on one hour later.
- Press TIME. The timing state is from one to eight hours and the corresponding green indicator light will be on. The number of indicator lights which are on will be accumulated. After the timing, it will change to standby state.
- Cancel is the reset key. Press it and it will cancel the functional state and switch to standby.

• Fault introductions

If the temperature indicator lights flicker alternatively, please check whether the coupler of the electric blanket has been connected firmly or not and restart it. If the fault cannot be removed, it means the internal connection in the electric blanket is faulty and repair is needed.

If the temperature indicator lights flicker at the same time, it means the temperature of the heating elements is too high. Please use the electric blanket after it cools down. If the fault cannot be removed, the electric blanket has been broken.

Disconnecting cord:

Please switch off the blanket after you get up, and then unplug the blanket from the power supply.

To remove the controller, lift the locking tab up with your finger and pull the plug directly out. Do not pull the controller cable. Do not pull out the controller plug without lifting the locking tab as you will damage the socket.

