



## Premium Heated Beauty Mitts



Congratulations on your purchase of ForPro Premium Heated Beauty Mitts. Please read the instructions and safety tips before use. Your mitts come with a one-year limited warranty. If for any reason you need service, please call 800-520-6000.

**IMPORTANT INSTRUCTIONS — RETAIN FOR FUTURE USE**

## FEATURES

ForPro Premium Heated Beauty Mitts provide a fabulous spa experience prior to the manicure service. Features two temperature settings and quick heating. The heat aids in the penetration of moisturizers to skin on hands. Oversized to fit all size hands. Recommend using with ForPro Cozies Liners.

## PRODUCT SPECIFICATIONS

Rated power: 110V/60Hz  
Power: 40W

## USER INSTRUCTIONS

1. Mitts have high and low temperature settings and OFF. Prior to each use turn the switch to the high position and let them heat for 15 minutes.
2. Remove all polish from hands.
3. Apply cuticle formula and/or hand cream and massage thoroughly over hands and fingers. (Fig. 1)
4. Insert hands into ForPro Cozies liners or plastic wrap. (Fig. 2)
5. Insert hands with liners into oversized heated mitts. (Fig. 3)
6. Lower the heat setting to low.
7. Leave hands in mitts for 15 minutes.

## SAFETY INSTRUCTIONS

To reduce risk of burns, electric shock and fire, this product must be used in accordance with the following instructions. Please read carefully.

- Do not use while sleeping.
- Keep away from children. Do not use on an infant.
- Do not use on an invalid, unconscious person, or person with poor blood circulation, unless carefully attended.
- Do not use on areas of insensitive skin.
- Burns can occur regardless of control setting. Check skin under pad frequently.
- Be sure to use with a disposable plastic liner.
- Do not use pins or other metallic means to fasten this product in place.
- Do not sit on or crush pad and avoid sharp folds.
- Never pull product by electrical cord or use as a handle.
- Carefully examine inside of mitt before each use. Discard if it shows signs of deterioration.
- This product has a polarized plug (one blade wider than the other) as a safety feature. Plug fits polarized outlet only one way. If the plug does not fit fully into outlet, reverse plug. If it still does not fit, contact a licensed electrician. Do not attempt to force the plug.
- Loop cord loosely when storing. Tight wrapping may damage cord and internal parts.



Fig. 1



Fig. 2



Fig. 3

**ForPro**  
Professional Collection™

Item #100596

tng worldwide • New Hudson, MI 48165

tngworldwide.com • 800.520.6000

©2019 TNG • Made in China